

HOW TO PLACE COLECOVISION'S COVER

1) First, place the screws upside down on the front side of the cover



2) Then place spacers of 5 mm



3) Place the colecovision card upside down



4) Place the spacer of 3 mm



5) Then place the back cover and nuts.



You can cut the screws that exceed, we let them overtake so that it is easier to screw the nuts